


## Synchronization of Custom Landing page to Pair Device


1. Log-in to GUI
2. On side menu, Navigate to Settings > High Availability



3. Ensure that the HA are established

Connected = Yes

Peer Data = UpToDate



4. Under "Synchronization" click "Synchronize" button.

